


WIRING DIAGRAM



CALIBRATION ACCORDING CYLINDER NUMBER THROUGH POTENTIOMETER

POTENTIOMETER KNOB

CENTRAL POSITION FOR SIX CYLINDER
TURN TO THE LEFT FOR FOUR CYLINDER
TURN TO THE RIGHT FOR EIGHT CYLINDER

